

Alphacool Leak Testing Tool incl. Pump

Alphacool article number: 17482

Download Center



Quick Info

After completing the water circuit, the last step is usually to fill the system. Every now and then, it happens that some liquid leaks out somewhere. This is often because a hard tube or hose is not seated correctly or a connection has not been screwed in completely. With the Alphacool Leak Testing Tool, you can test the tightness of your water circuit before filling the system.

- For up to 1 bar
- Pump included
- Simply connect via G1/4" connection
- Quick and easy to use

Scope of delivery

- 1x 40 cm tube with G1/4" thread
- 1x air pump
- 1x analog pressure indicator

Technical Data

L x W x H	82 x 98 x 28 mm
Tube length	40 cm
Tube	11/8 mm with anti-kink spring
Tube material	PVC
Tube color	Black
Thread	G1/4"
Maximum Pressure	Max. 1 Bar

Download links

Manual	17482_Alphacool_Leak_Testing_Tool_incl._Pump_Manual.pdf
Product pictures	17482_Alphacool_Leak_Testing_Tool_incl._Pump_pics.zip
EU-DoC / CE / RoHS	Alphacool_EuDoc_CE_RoHS_17482.pdf

Packaging dimensions per unit

L x W x H	220 x 160 x 50 mm
Weight	214 g

Other data

Certificates	CE, FC, RoHS
EAN	4250197174824
Customs code	90262040000

Article text

After completing the water circuit, the last step is usually to fill the system. Every now and then, it happens that some liquid leaks out somewhere. This is often because a hard tube or hose is not seated correctly or a connection has not been screwed in completely. With the Alphacool Leak Testing Tool, you can test the tightness of your water circuit before filling the system.

Construction

The leak testing tool consists of a hand pump, a pressure indicator, and an 11/8mm hose with a G1/4" thread connection at the end. The whole thing is connected using a TEE piece. The hose is 40 cm long and has an anti-kink spring.

Application

Connect the Alphacool Leak Testing Tool to a free G1/4" connection in the system and operate the hand pump until the desired pressure is reached. Please note that there may be different maximum specifications depending on the manufacturer. Now you should wait about 15 to 20 minutes. If the pressure has not dropped after this time, the water circuit is sealed.